



<b>Document Number</b>		DDB0004	
<b>Title</b>		ADL2 USB device driver	
<b>Approved By</b>		TW	
<b>Revision</b>	<b>Date</b>	<b>Prepared By</b>	<b>Change History</b>
A	17/01/2005	DS	

## Dealer Information Update

The following information printed on yellow paper and included with every ADL2 purchase.

-----

### Notes on ADL2 USB device driver installation

### Do not connect the ADL2 to the PC until you have installed ADL2 Dash Manager

If the ADL2 is connected before installing Dash Manager the drivers may not install correctly. If this happens see the "USB Troubleshooting" section in the readme notes supplied with ADL2 Dash Manager.

#### What should I do?

1. Install ADL2 Dash Manager on your PC. This will load the ADL2 USB device driver onto the PC ready for installation when the ADL2 is first connected.
2. Connect the ADL2 to the PC via the USB cable and turn on the ADL2 power. If this is the first time an ADL2 has been connected to the PC it will show a message indicating that a new hardware device has been found.
3. The steps required to complete the USB device driver installation will be different, depending on the version of Windows that you are running. Read the appropriate section below for instructions for your operating system.

If the ADL2 is not detected, or is unrecognized, or if a problem occurs during driver installation see the "USB Troubleshooting" section in the read me notes supplied with ADL2 Dash Manager.

#### Windows XP

1. When the ADL2 is connected, Windows will display a help balloon indicating that it has detected an ADL2.
2. The Found New Hardware Wizard will be displayed. On the first page of the Wizard select "Install the software automatically (Recommended)" then click "Next".
3. A dialog may be displayed warning that the driver has not passed Windows Logo testing. Click "Continue Anyway" to proceed with the installation.
4. Windows will automatically install the driver. Once the installation is complete click "Finish" to close the Wizard.

**Windows 2000**

1. When the ADL2 is connected, Windows will display a dialog indicating that it has detected an ADL2.

Windows will automatically install the driver. No further intervention should be necessary.

**Windows 95(B), Windows 98, Windows ME**

1. When the ADL2 is connected, Windows will display a dialog indicating that it has detected an ADL2.
2. If installing on Windows 95(B) or Windows 98 a dialog will be displayed asking you to insert a disk labelled "*MoTeC product installation disk*". You do not need to insert any disks, just press OK on this dialog to proceed.

3. Next, a dialog will be displayed stating that a file on the product installation disk cannot be found. All of the driver files are located in **C:\Program Files\MoTeC\Drivers**

If the "*Copy files from*" field does not already contain this path, click the "Browse..." button and navigate to the above folder, then click "OK" to close the Browse dialog.

Click "OK" to proceed with the installation.

4. Windows will automatically install the driver. No further intervention should be necessary.

-----

Should you have any further queries regarding this bulletin, do not hesitate to contact MoTeC support.

Ph: +61 3 9761 5050

Fax: +61 3 9761 6627

Email: [support@motec.com.au](mailto:support@motec.com.au)